




Water-Resistant  
Bluetooth® Speaker

### Quick Guide



- 1) To prevent the risk of electric shocks, please do not charge this product near water.
- 2) Do **NOT** drop, submerge, or use the Spot Shower under water.

### 1 Overview



：On / Off

：Play / Pause

：Call / End

MIC : Microphone

：Forward

：Backward

：Volume up (Hold)


：Volume down (Hold)

### 2 Battery Charge



To prevent the risk of electric shocks, please do not charge this product near water.

### 3 Pairing



### 4 Receiving & Ending calls

